




### MXH Series Small Pneumatic Slide (Liner Guide)

- Cylinder
- Calculation
- SI
- SI A.
- SIB
- SQ
- DNT
- SC / SU
- SCT
- SC A.
- SL
- DN
- DSN
- DN/DSN A.
- MA
- MAC
- MA/MAC A.
- MAL
- MALC
- MAL/MALC A.
- SDA
- CQ2
- TCQ2
- ADN
- TADN
- PPRM
- MHL2
- Pneumatic  
Fingers
- MXH/MXQ
- CJP
- CJ2
- CDU
- TN
- CXS
- MGP
- MSQ


#### Ordering Code

MXH	10	30	MT	□
Series	Bore	Stroke	Sensor Switch	Number of Sensor Switch
Built-in magnetic ring	6: Φ6mm 10: Φ10mm 16: Φ16mm 20: Φ20mm	5 30 10 40 15 50 20 60 25	D-A93 	Blank : 2 S : 1
			* Standard wire length is 1 meter, please specify for other length	



### MXQ Series Pneumatic Slide

#### Ordering Code

MXQ	12	L	50	AS	FR	MT	□
Bore	Stroke	Stroke Adjuster (Options)	Functional Options	Sensor Switch	Number of Sensor Switch		
6: Φ6mm 8: Φ8mm 12: Φ12mm 16: Φ16mm 20: Φ20mm 25: Φ25mm	Blank: Standard L: Symmetrical type	Blank AS AT A BS BT B CS CT C	No Rubber Stopper Hydraulic Buffer (*1) Metal Stopper	Blank: No F: Spring Buffer R: End Lock (*2) P: Axial Takeover FR: Spring Buffer and End Lock (*2) FP: Spring Buffer and Axial Takeover	D-A93 	Blank : 2 S : 1 n : n	
				* Standard wire length is 1 meter, please specify for other length			
				*2: Not applicable to MXQ6			

\*1: Not applicable to MXQ6